




4' Grand Contour Laser Direct Bury Swing

971-S02



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	635-002	Contour Swing Direct Bury Post	2
2	635-012	4' CONTOUR SWING BRACE	1
3	SH105	Swing WB Hanger	2
4	S-Hook	Swing Hook	2
5	625-S04	4' Grand Contour Laser Swing Bench	1
6	635-100	GC Swing Chain Harness	2
7	516-065	1/2"x5" SS Hex Bolt	4
8	516-036	1/2" SS NyLock Nut	4
9	516-027	1/2" SS Flat Washer	8
10	516-058	3/8"x1-1/2" SS Hex Bolt	4
11	516-028	3/8" SS Nylock Nut	4
12	516-023	3/8" SS Flat Washer	8



PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.



SIZE

A

Sheet 1 OF 2



4' Grand Contour Laser Direct Bury Swing


971-S02

Tools List

- 7/16" Drill bit
- 9/16" Drill bit
- 9/16" Socket
- 3/4" Socket
- 9/16" Wrench
- 3/4" Wrench
- Level
- Impact Gun (Optional)
- Drill

This product uses Hardware Pack HWPK14 (you may receive extra hardware)

- 4 qty. 3/8" x 1-1/2" SS Hex Bolt
- 4 qty. 3/8" SS Nylock Nut
- 8 qty. 3/8" SS Flat Washer
- 4 qty. 1/2" x 5" SS Hex Bolt
- 4 qty. 1/2" SS Nylock Nut
- 4 qty. 1/2" SS Washer
- 2 qty. H-14 S-Hook



1. Bore two 12" diameter holes into the ground as per drawing.
2. The holes should be at least 30" deep as shown or below the frost line in your area, which ever is greater.
3. Drill out plastic from all mounting holes on the swing seat with a 7/16" drill bit.
4. Drill out plastic from all mounting holes on the posts and brace with a 9/16" drill bit.
5. Bolt items 1, 2 and 4 together using the 1/2" fixings provided.
6. Place the posts into the holes and support them.
7. Attach the s-hooks onto the swing WB hangers.
8. Attach the chains to the s-hooks.
9. Bolt the swing seat to the chains using 3/8" fixings provided.
10. Level swing seat and adjust posts to desired height. Recommended height is 18" from the ground to the top front of the seat.
11. Fill the holes with concrete to approximately 2" below ground level or fill to no higher than ground level and crown the top so that water will run off.
12. Let stand for 24 hours before removing the supports.

Periodic check of bolts tightness recommended



PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.

