



- 1 Drill plastic out of the mounting holes with a 7/16" dia. drill bit.
- 2 Position bike rack where desired.
- 3 Secure to the surface with the appropriate fasteners.

In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

Periodic check of bolt tightness recommended.

