



4' CHAMPION WITHOUT BACK, DIRECT BURY

935-102





ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-020	Bench Stand DB	2
2	622-011	Champion 4' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4





PREMIER POLYSTEEL












DETAIL A SCALE 1:5



DETAIL B SCALE 1:5

- 1. Drill plastic out of the mounting holes on the legs and seat using a 7/16" diameter drill bit.
- 2. Bolt the seat to the legs and tighten up.
- 3. Mark out the holes for the legs on the ground in the desired location. Drill 10" diameter holes at each location to a minimum depth of 30". You need to be below the frost line in your area.
- 4. Place the seat into the holes and support at the desired height. Level the seat.
- 5. Fill the holes with concrete and crown the top so that water will run off. Let stand for 24 hours before removing the supports.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- 7/32" Allen Wrench
- Imapct Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL










ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-020	Bench Stand DB	2
2	622-013	Champion 6' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4









- 1. Drill plastic out of the mounting holes on the legs and seat using a 7/16" diameter drill bit.
- 2. Bolt the seat to the legs and tighten up.
- 3. Mark out the holes for the legs on the ground in the desired location. Drill 10" diameter holes at each location to a minimum depth of 30". You need to be below the frost line in your area.
- 4. Place the seat into the holes and support at the desired height. Level the seat.
- 5. Fill the holes with concrete and crown the top so that water will run off. Let stand for 24 hours before removing the supports.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL










ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-020	Bench Stand DB	2
2	622-015	Champion 8' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4







- 1. Drill plastic out of the mounting holes on the legs and seat using a 7/16" diameter drill bit.
- 2. Bolt the seat to the legs and tighten up.
- 3. Mark out the holes for the legs on the ground in the desired location. Drill 10" diameter holes at each location to a minimum depth of 30". You need to be below the frost line in your area.
- 4. Place the seat into the holes and support at the desired height. Level the seat.
- 5. Fill the holes with concrete and crown the top so that water will run off. Let stand for 24 hours before removing the supports.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL










ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-016	Champion 10' Seat/Back	1
2	631-020	Bench Stand DB	3
3	516-058	3/8"x1-1/2" SS Hex Bolt	6
4	516-023	3/8" SS Flat Washer	12
5	516-028	3/8" SS Nylock Nut	6







1. Drill plastic out of the mounting holes on the legs and seat using a 7/16" diameter drill bit.

SCALE 1:8

- 2. Bolt the seat to the legs and tighten up.
- 3. Mark out the holes for the legs on the ground in the desired location. Drill 10" diameter holes at each location to a minimum depth of 30". You need to be below the frost line in your area.
- 4. Place the seat into the holes and support at the desired height. Level the seat.
- 5. Fill the holes with concrete and crown the top so that water will run off. Let stand for 24 hours before removing the supports.

Tools List

• 7/16" Drill bit

SCALE 1:8

- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended

In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL










ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-010	Bench Stand FS	2
2	622-011	Champion 4' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	6
4	516-054	3/8"x2" SS Hex Head Bolt	1
5	516-023	3/8" SS Flat Washer	14
6	516-028	3/8" SS Nylock Nut	7
7	631-313	BRACE	2









- Drill plastic out of the mounting holes on the seat, stands and braces using a 7/16" 1. diameter drill bit.
- Bolt the seat to the stand and braces loosely using fixings provided. Set on level 2. surface and tighten up.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Imapct Gun (Optional)
- Drill


Periodic check of bolts tightness reccommended
In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.















ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-010	Bench Stand FS	2
2	622-013	Champion 6' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	8
4	516-023	3/8" SS Flat Washer	16
5	516-028	3/8" SS Nylock Nut	8
6	631-313	BRACE	2









- 1. Drill plastic out of the mounting holes on the seat, stands and braces using a 7/16" diameter drill bit.
- 2. Bolt the seat to the stand and braces loosely using fixings provided. Set on level surface and tighten up.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill


Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL










ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	631-010	Bench Stand FS	2
2	622-015	Champion 8' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	8
4	516-023	3/8" SS Flat Washer	16
5	516-028	3/8" SS Nylock Nut	8
6	631-313	BRACE	2









- 1. Drill plastic out of the mounting holes on the seat, stands and braces using a 7/16" diameter drill bit.
- 2. Bolt the seat to the stand and braces loosely using fixings provided. Set on level surface and tighten up.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.





PREMIER POLYSTEEL












ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-016	Champion 10' Seat/Back	1
2	631-010	Bench Stand FS	3
3	516-058	3/8"x1-1/2" SS Hex Bolt	12
4	516-023	3/8" SS Flat Washer	24
5	516-028	3/8" SS Nylock Nut	12
6	631-313	BRACE	3









- 1. Drill plastic out of the mounting holes on the seat, stands and braces using a 7/16" diameter drill bit.
- 2. Bolt the seat to the stand and braces loosely using fixings provided. Set on level surface and tighten up.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapet Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL









- 1. Drill plastic out the mounting holes on the stands and seat using 7/16"diameter drill bit
- 2. Attach the stands to the seat using fixings provided.
- 3. Stand the bench in its final location and mark out base holes.
- 4. Move the bench to a safe place and drill holes.
- 5. Place the bench back, level and secure down using appropriate fixings for the ground material.


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-011	Champion 4' Seat/Back	1
2	633-011	Bench Stand Without Back	2
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4











- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Imapct Gun (Optional)
- Drill
- Level

Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.





PREMIER POLYSTEEL

PROUDLY MADE IN THE USA










ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	633-011	Bench Stand Without Back	2
2	622-013	Champion 6' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4









- 1. Drill plastic out the mounting holes on the stands and seat using 7/16" diameter drill bit.
- 2. Attach the stands to the seat using fixings provided.
- 3. Stand the bench in its final location and mark out base holes.
- 4. Move the bench to a safe place and drill holes.
- 5. Place the bench back, level and secure down using appropriate fixings for the ground material.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.





PREMIER POLYSTEEL












ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-015	Champion 8' Seat/Back	1
2	633-011	Bench Stand Without Back	2
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4









- 1. Drill plastic out the mounting holes on the stands and seat using 7/16" diameter drill bit.
- 2. Attach the stands to the seat using fixings provided.
- 3. Stand the bench in its final location and mark out base holes.
- 4. Move the bench to a safe place and drill holes.
- 5. Place the bench back, level and secure down using appropriate fixings for the ground material.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill

Periodic check of bolts tightness reccommended


In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL










- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- 7/32" Allen Wrench
- Imapct Gun (Optional)
- Drill



- 1. Drill plastic out the mounting holes on the stands and seat using 7/16" diameter drill bit.
- 2. Attach the stands to the seat using fixings provided.
- 3. Stand the bench in its final location and mark out base holes.
- 4. Move the bench to a safe place and drill holes.
- 5. Place the bench back, level and secure down using appropriate fixings for the ground material.

Periodic check of bolts tightness reccommended

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-016	Champion 10' Seat/Back	1
2	633-011	Bench Stand Without Back	3
3	516-058	3/8"x1-1/2" SS Hex Bolt	6
4	516-023	3/8" SS Flat Washer	12
5	516-028	3/8" SS Nylock Nut	6




PREMIER POLYSTEEL












In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.




PREMIER POLYSTEEL










ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	634-001	Wall Mount Bench Without Back	2
2	622-011	Champion 4' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4










- Drill plastic out of the mounting holes on the brackets and seat using a 7/16" 1. diameter drill bit.
- 2. Fix the brackets to the seat using the bolts provided and tighten up.
- Hold the seat up against the wall in it's final location and mark out fixing holes. 3.
- Place the seat in a safe location and drill holes using appropriate drill bit. 4.
- 5. Lift up seat and fix in place using the correct fixings for the wall material.


- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill


Periodic check of bolts tightness reccommended
In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.












ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	634-001	Wall Mount Bench Without Back	2
2	622-013	Champion 6' Seat/Back	1
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4









- 1. Drill plastic out of the mounting holes on the brackets and seat using a 7/16" diameter drill bit.
- 2. Fix the brackets to the seat using the bolts provided and tighten up.
- 3. Hold the seat up against the wall in it's final location and mark out fixing holes.
- 4. Place the seat in a safe location and drill holes using appropriate drill bit.
- 5. Lift up seat and fix in place using the correct fixings for the wall material.

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Imapct Gun (Optional)
- Drill


Periodic check of bolts tightness reccommended

In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.



PREMIER POLYSTEEL





- Drill plastic out of the mounting holes on the stands and seat using a 7/16" dia. drill bit.
- 2. Fasten the seat to the stands.
- Anchor to the wall with the appropriate fasteners.


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-015	8' Champion Seat/Back	1
2	634-001	Wall Mount Bracket	2
3	516-058	3/8"x1-1/2" SS Hex Bolt	4
4	516-023	3/8" SS Flat Washer	8
5	516-028	3/8" SS Nylock Nut	4



PREMIER POLYSTEEL





- Drill plastic out of the mounting holes on the stands and seat using a 7/16" dia. drill bit.
- Fasten the seat to the stands.

3. Anchor to the wall with the appropriate fasteners.
In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-016	10' Champion Bench/Back	1
2	634-001	Wall Mount Bracket	3
3	516-058	3/8"x1-1/2" SS Hex Bolt	6
4	516-023	3/8" SS Flat Washer	12
5	516-028	3/8" SS Nylock Nut	6



PREMIER POLYSTEEL

