



1. Drill plastic out of the mounting holes with a 7/16" dia. drill bit.
2. Position bike rack where desired.
3. Secure to the surface with the appropriate fasteners.

In Accordance to California law: WARNING This product contains a chemical known to the State of Calif