





# 3' Champion Expanded Metal Free Standing Children's Square Picnic Table **944-091**



| ITEM NO. | PART NUMBER | DESCRIPTION                            | QTY. |
|----------|-------------|----------------------------------------|------|
| 1        | 642-311     | 3' Square Expanded Table               | 1    |
| 2        | 634-311     | 3' Square Kids Table Leg               | 8    |
| 3        | 634-119     | Square Table Leg X Brace               | 1    |
| 4        | 622-319     | 30" Champion Seat for 3' Sq Kids Table | 4    |
| 5        | 516-058     | 3/8"x1-1/2" SS Hex Bolt                | 32   |
| 6        | 516-023     | 3/8" SS Flat Washer                    | 64   |
| 7        | 516-028     | 3/8" SS Nylock Nut                     | 32   |




## PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.





# 3' Champion Expanded Metal Free Standing Children's Square Picnic Table 944-091



1. Drill the plastic out of all mounting holes using a 7/16" drill bit.
2. With table top upside down bolt 2 opposing legs on to top. Do not tighten the bolts now.
3. Attach "x" shaped leg brace to the 2 legs.
4. Attach the other 6 legs fastening to the "x" shaped leg brace as you go.
5. Attach seats to other end of leg. The vertical portion of the angle iron leg top bolts flush with
6. the seat support bar.
7. Flip the table right side up, level the top and seats, and tighten all of the bolts.

*Periodic check of bolts tightness recommended*

## Tools List

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Impact Gun (Optional)
- Drill

This product uses Hardware Pack HWPK01  
(you may receive extra hardware)

32 qty. 3/8" x 1-1/2" SS Hex Bolt

32 qty. 3/8" SS Nylock Nut

64 qty. 3/8" SS Flat Washer



## PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.

