




# 4' Champion Free Standing Kids Table

941-101



| ITEM NO. | PART NUMBER | DESCRIPTION             | QTY. |
|----------|-------------|-------------------------|------|
| 1        | 642-211     | Champion Kids Table     | 1    |
| 2        | 634-210     | Kids Table Stand        | 2    |
| 3        | 622-011     | Champion 4' Seat/Back   | 2    |
| 4        | 634-211     | 4' Kids Table Brace     | 1    |
| 5        | 516-058     | 3/8"x1-1/2" SS Hex Bolt | 14   |
| 6        | 516-023     | 3/8" SS Flat Washer     | 28   |
| 7        | 517-028     | 3/8" Zinc Nylock Nut    | 14   |




## PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.



SIZE  
A

REV. X.01 | SHEET 1 OF 2



## Tools List

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Drill

1. Drill out plastic from all mounting holes using a 7/16" drill bit.
2. Flip the table top upside down and attach the stands loosely using fixings provided. Protect the table top by placing cardboard between it and the ground. Do not tighten up bolts at this stage.
3. Attach the brace as shown.
4. Flip the table back to the correct position and attach the seats to the stands.
5. Level the seats and table then tighten up all bolts.

*Periodic check of bolts tightness recommended*

In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.



## PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.

