





PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.



Note that the legs are on the right side of the support frame.



1. Assemble the table upside down. Protect the Table top from scratches by placing cardboard between it and the concrete floor.
2. Drill out holes in the Table Top, Legs and Leg Brace using a 7/16" dia. drill bit.
3. Attach the legs to the Table Top with a bolt, 2 washers & locknut. *Do not tighten the bolts and locknuts at this time.*
4. Attach the Leg Brace with flat top towards the Table Top. Use a locknut and washer on each threaded stud. *Do not tighten at this time.*
5. Set table upright on a level surface and tighten all the hardware. *Make sure that the Table Top is level as you tighten the hardware.*

In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.

TITLE:

SIZE
A

DWG. NO.
908-D81

REV

SCALE: 1:8


WEIGHT:

SHEET 1 OF 2




PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.



Ø 30"



27 3/8"

TITLE:

SIZE
A

DWG. NO.
908-D81

REV

SCALE: 1:8

WEIGHT:

SHEET 2 OF 2

5

↑

4

3

2

1