




# CHAMPION 10' WITHOUT BACK, DIRECT BURY

935-602



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	622-016	Champion 10' Seat/Back	1
2	631-020	Bench Stand DB	3
3	516-058	3/8"x1-1/2" SS Hex Bolt	6
4	516-023	3/8" SS Flat Washer	12
5	516-028	3/8" SS Nylock Nut	6





## PREMIER POLYSTEEL


The Best Commercial Outdoor Furniture Available. Period.



SIZE  
**A**



DETAIL A  
SCALE 1 : 8



DETAIL B  
SCALE 1 : 8

1. Drill plastic out of the mounting holes on the legs and seat using a 7/16" diameter drill bit.
2. Bolt the seat to the legs and tighten up.
3. Mark out the holes for the legs on the ground in the desired location. Drill 10" diameter holes at each location to a minimum depth of 30". You need to be below the frost line in your area.
4. Place the seat into the holes and support at the desired height. Level the seat.
5. Fill the holes with concrete and crown the top so that water will run off. Let stand for 24 hours before removing the supports.

Tools List

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- Level
- Impact Gun (Optional)
- Drill

*Periodic check of bolts tightness recommended*

In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.



**PREMIER POLYSTEEL**

The Best Commercial Outdoor Furniture Available. Period.

