



- Attach both legs to the inside of table support bar
- Attach the straight end of each brace to the table.
- Attach bent end of both braces to the cross bar of each leg.

Part No.	Description	Qty.
642-A15	8' Champion Accessible Top	1
622-013	6' Champion Seat/Back	2
634-010	Free Standing Table Stand	2
634-013A	Table Brace w/Umbrella Hole	2
516-058	3/8" X 1-1/2" SS Hex Bolt	16
516-028	3/8" SS Nylock Nut	16
516-023	3/8" SS Flat Washer	32

Assembly Instructions


- 1 Drill out holes on the Table Top, Seats, Stands and Braces with a 7/16" dia. drill.
- 2 Attach the Stands to the Table Top loosely using the 3/8" x 1-1/2" SS Bolts. (See photo above right)
- 3 Attach the Seats to the Stands loosely using the 3/8" x 1-1/2" SS Bolts.
- 4 Attach Braces to the Stands and Table Top loosely using the 3/8" x 1-1/2" SS Bolts. (See photo above right)
- Tighten all bolts.


 In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.


 Periodic check of bolt tightness recommended.














PREMIER POLYSTEEL





Assembly Instructions

- 1. Drill out holes.
- 2. Attach both legs to the inside of table support bar. (See view above)
- 3. Attach the seats to the legs.
- 4. Attach the straight end of each brace to the table. (See view above)
- 5. Attach bent end of both braces to the cross bar of each leg. (See view above)

In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	642-AP5	8' Champion Accessible Table Top	1
2	622-P13	6' Champion Perf Seat/Back	2
3	634-010	FS Table Stand (10" Seats)	2
4	634-013A	Table Brace W/Umbrella	2
5	516-058	3/8"x1-1/2" SS Hex Bolt	14
6	516-023	3/8" SS Flat Washer	28
7	516-028	3/8" SS Nylock Nut	14




PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.







Part No.	Description	Qty.
642-A15	Champion Accessible Table Top 8'	1
622-013	Champion Seat/Back 6'	2
632-200	Table Pedestal Direct Bury	2
516-058	3/8" X 1-1/2" SS Hex Bolt	12
516-028	3/8" SS Nylock Nut	12
516-023	3/8" SS Flat Washer	24


- 1 Drill 2 holes in ground per the above drawing.
- 2 Place the pedestals in the holes.
- 3 Drill plastic out of the mounting holes on the pedestals, top and seats using a 7/16" dia. drill bit.
- Fasten the table top to the pedestals, support and level table top. Check height.
- Fasten the seats to the pedestals, support and level seats. Check height.
- 6 When the seats and top are level and secured fill the holes with concrete to about 2" below ground level.


In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.

Periodic check of bolt tightness recommended.









- 1.
- Drill plastic out of the mounting holes on the pedestals, top and seats using a 7/16" dia. drill bit. Fasten the table top and seats to the pedestals, installing the pedestal on the inside of the table 2. and seat mounting bar.
- Position the table and seats and anchor them to the floor.

In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.














ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	642-A15	8' Accessible Table Top Expanded	1
2	622-013	Champion Seat/Back 6'	2
3	633-131	Table Pedestal Stand (Surface Mount)	2
4	633-141	Seat Pedestal Stand (Surface Mount)	4
5	516-058	3/8"x1-1/2" SS Hex Bolt	12
6	516-028	3/8" SS Nylock Nut	12
7	516-023	3/8" SS Flat Washer	24





PREMIER POLYSTEEL


The Best Commercial Outdoor Furniture Available. Period














PREMIER POLYSTEEL







In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.

- 1. With table top upside down bolt 2 opposing legs on to top. Do not tighten the bolts now.
- 2. Attach "x" shaped leg brace to the 2 legs.
- 3. Attach the other 6 legs fastening to the "x" shaped leg brace as you go.
- 4. Attach seats to other end of leg. The vertical portion of the angle iron leg top bolts flush with the seat support bar.
- 5. Flip the table right side up, level the top and seats, and tighten all of the bolts.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	642-115	4x5 Accessible table Top	1
2	634-111	Sq./Rnd Table Free Standing Leg	6
3	634-112	3 Seat Leg for Sq/Round Table	2
4	622-019	40" Champion Seat	3
5	634-119	Sq./Rnd Table Leg Support Bracket	1
6	516-058	3/8"x1-1/2" SS Hex Bolt	28
7	516-023	3/8" SS Flat Washer	56
8	516-028	3/8" SS Nylock Nut	28



PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available, Period.

