

- Drill plastic out of the mounting holes on the seat, braces and stands using a 7/16" dia. drill bit. Fasten the seat to the stands loosely and then fasten the brace to the stands and seat. Make sure the bench is level and tighten all the bolts.
- 2.
- 3.
- Position bench where desired and anchor to the floor.

In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	733-013	Grand Contour Free Standing Bench Stand	2
2	623-014	4' Grand Contour Expanded Metal Seat	1
3	631-313	Brace for FS Bench	2
4	516-058	3/8"x1-1/2" SS Hex Bolt	4
5	516-033	3/8"x4" SS Button Head Cap Screw	4
6	516-023	3/8" SS Flat Washer	16
7	516-028	3/8" SS Nylock Nut	8



