

- 1. Drill plastic out of the holes using a 7/16" diameter drill bit.
- 2. Attach both legs to the inside of the table support bar (see view above).
- 3. Attach the seats to the legs.
- 4. Attach the straight end of each brace to the table (see view above).
- 5. Attach the bent end of each brace to the cross bar of each leg (see view above).
- 6. Tighten up all fixings.


In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.


		-	
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	642-011	4' Champion Table Top	1
2	634-010	Free Standing Table Stand For Seats	2
3	622-011	Champion 4' Seat/Back	2
4	634-011	4ft FS Table Brace 19 1/4"	2
5	516-058	3/8"x1-1/2" SS Hex Bolt	16
6	516-023	3/8" SS Flat Washer	32
7	516-028	3/8" SS Nylock Nut	16
			•




PREMIER POLYSTEEL









- 1. Drill out holes.
- 2. Attach both legs to the inside of table support bar. (See view above)
- 3. Attach the seats to the legs.
- 4. Attach the straight end of each brace to the table. (See view above)

5. Attach bent end of both braces to the cross bar of each leg. (See view above)


In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	642-0P1	4' Champion Perforated Metal Table Top	1
2	634-010	FS Table Stand (10" Seats)	2
3	622-0P1	4' Champion Perforated Seat/Back	2
4	634-011	4ft Free Standing Table Brace	2
5	516-058	3/8"x1-1/2" SS Hex Bolt	16
6	516-023	3/8" SS Flat Washer	32
7	516-028	3/8" SS Nylock Nut	16




PREMIER POLYSTEEL





REV. X.01 SHEET 1 OF 2



Periodic check of bolts tightness reccommended


In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.





PREMIER POLYSTEE




he Best Commercial Outdoor Furniture Available. Period.









- 2. Attach both stands to the inside of table support bar loosley with fixings provided. (See diagram above)
- 3. Attach the seats to the stands.
- 4. Attach the straight end of each brace to the table. (See diagram above)
- 5. Attach bent end of both braces to the cross bar of each stand. (See diagram above)
- 6. Set on level surface and tighten up bolts.

<u>Tools List</u>

- 7/16" Drill bit
- 9/16" Socket
- 9/16" Wrench
- 7/32" Allen Wrench
- Drill

Periodic check of bolts tightness reccommended

In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.



'he Best Commercial Outdoor Furniture Available, Period.

