
| ITEM NO. | PART NUMBER | DESCRIPTION | Default/Q TY. |
|----------|-------------|--------------------------------------|------------------|
| 1 | 670-004 | Lounge Chair Base Frame | 1 |
| 2 | 670-002 | Lounge Chair Seat | 1 |
| 3 | 670-012 | Chaise Lounge Back | 1 |
| 4 | 670-014 | Chaise Lounge Brace | 1 |
| 5 | 520-100 | Chaise Lounge Chair Wheel | 2 |
| 6 | 520-110 | 1/2" Axle Cap | 2 |
| 7 | 516-031 | 3/8"x1-3/4" SS Btn Skt Cap Screw | 2 |
| 8 | 516-032 | 3/8"x3-1/2" SS Button Head Cap Screw | 2 |
| 9 | 516-068 | 1/2"X2" SS Button Head Cap Screw | 2 |
| 10 | 516-067 | 1/2"X2-1/2" SS Button Head Cap Screw | 2 |
| 11 | 516-023 | 3/8" SS Flat Washer | 8 |
| 12 | 516-028 | 3/8" SS Nylock Nut | 4 |
| 13 | 516-027 | 1/2" SS Flat Washer | 12 |
| 14 | 516-036 | 1/2" SS NyLock Nut | 4 |

900-101







PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.



Tools needed:

900-101


3/8" & 1/2" Drill Bit. Electric Drill Pliers 5/16" & 7/32" Hex Wrench 9/16" & 3/4" Socket & rachet or 9/16" & 3/4" Box End Wrench Hammer




1. With the 3/8" drill bit

- 2. With a 1/2" drill bit, drill out the 2 holes on the base where the back connects. Also drill out the 4 holes on the back where it connects to the base and the brace. The holes on the brace should be drilled out at this time too.
- 3. Attach the back to the base using the (2) 1/2"x2" Socket Head Cap Screws. Place a washer on the cap screw and insert it into the base, place another washer on the cap screw between the base and the back. Now push the cap screw through the back and attach a washer & locknut. Do not tighten at this time. Repeat step 2 for oppisite side of the base. Now tighten the cap screws so that the back will swing freely up and down.
- 4. Attach the brace to the back using the (2) 1/2"x2-1/2" Socket Head Cap Screws. Place a washer on the cap screw and insert it into the back, place another washer on the cap screw between the back and the brace. Push the cap screw through the brace and place another washer on the cap screw & a locknut. Do not tighten at this time. Repeat step 3 for the opposite side of the back. Now tighten the cap screws so that the brace swings freely.
- 5. Using a pliers grab the plastic coating on the axle and twist & pull it off. Place a washer on the axle, then install the wheel. Now place the axle cap on the axle and tap it on with a hammer.

In Accordance to California law: WARNING This product contains a chemical know to the State of California to cause cancer and birth defects or other reproductive harm.







PREMIER POLYSTEEL

The Best Commercial Outdoor Furniture Available. Period.



