


REV. X.01 SHEET 1 OF 2

he Best Commercial Outdoor Furniture Available. Period



- Place the tabletop upside down on top of a pair of sawhorses or 12" blocks (cover the blocks with 1. cardboard) and drill out the 8 holes in the frame using a 7/16" drill bit. Drill out the 8 holes in the leg bracket with the same 7/16" drill bit.
- 2. 3.
- Drill out the 6 holes on each of the table legs using the 7/16" drill bit.
- 4. Attach the leg top to the inside of the tabletop frame with a hex bolt, 2 washers and a nylock nut. Do not tighten completely.
- Repeat step 4 by attaching another leg on the same side as the first. 5.
- 6. Attach the leg bracket to the threaded stud on the 2 legs that you just attached to the tabletop. Use a washer and nylock nut. Again do not tighten completely.
- 7. Continue attaching the legs to the tabletop and leg bracket. When you have all of the legs attached, flip the table right side up.
- Drill out the 4 holes in the seat/back and install them onto the legs. Note: The cross frames on the 8. seat/back aren't the same distance from the ends. Be sure to align the seat with the back. The cross frame on the seat/back attaches to the same side of the mounting plate on each leg. (Both on the left or both on the right)
- When you have all of the parts attached you can begin tightening the bolts. Make sure the table is on a 9. level surface and adjust the legs and set/backs so that they are level as you tighten each component.



