




PREMIER POLYSTEEL





In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

Periodic check of bolt tightness recommended.

- 1. Assemble the table upside down. Protect the Table top from scratches by placing cardboard between it and the concrete floor.
- 2. Drill out holes in the Table Top, Legs and Leg Brace using a 7/16" dia. drill bit.
- 3. Attach the legs to the Table Top with a bolt, 2 washers & locknut. Do not tighten the bolts and locknuts at this time.
- 4. Attach the Leg Brace with flat top towards the Table Top. Use a locknut and washer on each threaded stud. *Do not tighten at this time.*
- 5. Set table upright on a level surface and tighten all the hardware. *Make sure that the Table Top is level as you tighten the hardware.*


| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|-------------|-------------------------|------|
| 1 | 642-B30 | 30" Expanded Table Top | 1 |
| 2 | 634-541 | Bar Table Leg | 4 |
| 3 | 634-542 | Leg Brace | 1 |
| 4 | 516-058 | 3/8"x1-1/2" SS Hex Bolt | 8 |
| 5 | 516-023 | 3/8" SS Flat Washer | 20 |
| 6 | 516-028 | 3/8" SS Nylock Nut | 12 |




PREMIER POLYSTEEL









Periodic checking of bolt tightness is recommended. (3)

| l | | | |
|----------|-------------|---------------------------|------|
| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
| 1 | 642-B35 | 30" Round Table Top Laser | 1 |
| 2 | 634-541 | Bar Table Leg | 4 |
| 3 | 634-542 | Leg Brace | 1 |
| 4 | 516-058 | 3/8"x1-1/2" SS Hex Bolt | 8 |
| 5 | 516-023 | 3/8" SS Flat Washer | 20 |
| 6 | 516-028 | 3/8" SS Nylock Nut | 12 |




PREMIER POLYSTEEL















| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|-------------|---------------------------------|------|
| 1 | 639-501 | Bar Height Chair Stand | 1 |
| 2 | 625-009 | Laser Deck Seat | 1 |
| 3 | 516-023 | 3/8" SS Flat Washer | 8 |
| 4 | 516-067 | 3/8"x2-1/2" SS Btn Skt Cap Scr. | 4 |
| 5 | 516-028 | 3/8" SS Nylock Nut | 4 |
| 6 | 516-061 | Leg Glide | 4 |



PREMIER POLYSTEEL








- If the Leg Glides are not installed, screw them into the bottom of the stands first. Drill the plastic out of the slots on both sides of the seat and the tubes at the top of the 2. stand using a 7/16" drill bit.
- Attach the seat to the stand using the Button Socket Cap Screws, Washers, and Nylock Nuts. Do not tighten the nuts until all four of the Button Socket Cap Screws 3. have been installed.
- 4. Tighten all of the Nuts until the washers are pressed into the plastic coating to the thickness of the Washer.
 Periodic checking of bolt tightness is recommended.


In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.












| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|-------------|---------------------------------|------|
| 1 | 639-501 | Bar Height Chair Stand | 1 |
| 2 | 623-007 | Expanded Deck Seat | 1 |
| 3 | 516-023 | 3/8" SS Flat Washer | 8 |
| 4 | 516-067 | 3/8"x2-1/2" SS Btn Skt Cap Scr. | 4 |
| 5 | 516-028 | 3/8" SS Nylock Nut | 4 |
| 6 | 516-061 | Leg Glide | 4 |
| | | | |



PREMIER POLYSTEEL







- 1. If the Leg Glides are not installed, screw them into the bottom of the stands first.
- 2. Drill the plastic out of the slots on both sides of the seat and the tubes at the top of the stand using a 7/16" drill bit.
- 3. Attach the seat to the stand using the Button Socket Cap Screws, Washers, and Nylock Nuts. Do not tighten the nuts until all four of the Button Socket Cap Screws have been installed.
- 4. Tighten all of the Nuts until the washers are pressed into the plastic coating to the thickness of the Washer.

 Periodic checking of bolt tightness is recommended.

In accordance to California law: WARNING - This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.



PREMIER POLYSTEEL



